

# BLADE

## leather | 1827 (637-01 pebble, 637-72 ridge)

SH = Seat Height | SW = Seat Width SD = Seat Depth | AH = Arm Height

OD = Open Depth | WC = Wall Clearance



1827-62PH
Power Reclining Sofa with
Power Headrests
41H 84W 42D
20SH 65SW 22SD 26AH 67OD 4WC



1827-64PH
Power Reclining
Loveseat with Console and
Power Headrests
41H 74W 42D
20SH 42SW 22SD 26AH 67OD 4WC



1827-60PH
Power Reclining
Loveseat with
Power Headrests
41H 62W 42D
20SH 43SW 22SD 26AH 67OD 4WC



1827-54PH
Power Gliding Recliner with Power
Headrest
41H 40W 42D
20SH 21SW 22SD 26AH 65OD 11WC

## Warranty Information

#### Lifetime Limited Warranty:

Springs, wood frames, seat cushions, and reclining mechanisms

### Five-Year Limited Warranty:

Mechanical and electrical components

## ${\bf One\mbox{-}Year\ Limited\ Warranty:}$

Upholstery materials

Visit www.flexsteel.com for complete warranty details.



Strength on the inside.
Lasting beauty on the outside.

At the heart of our upholstered furniture, our Blue Steel Spring<sup>™</sup> provides a comfortable sit that is guaranteed for the life of your product.